



















SPARES AND CONSUMABLES	MAINTENANCE ROUTINE (HOURS)	TO REPLACE MFR-HDCA
<p>MFR-DC10 MFR-DC100</p> 	  <p>AC-VPF</p>	<p>1</p> 
<p>MFR-PG</p> 	<p>CONFIGURE HAND-PIECE</p> <p>1</p> 	<p>2</p> 
<p>AC-VP</p> 	<p>2</p> 	<p>3</p> 
<p>AC-VL</p> 	<p>2</p> 	<p>3</p> 
<p>AC-SK1</p>  <p>x2</p>	<p>2</p> 	<p>3</p> 
<p>MFR-HDCA</p>  <p>x3</p>	<p>2</p> 	<p>3</p> 